

IKEGAMI TECHNICAL

# BULLETIN

37 Brook Avenue, Maywood, New Jersey 07607. (201) 368-9171, Fax (201) 368-2029

Ref No:  
Date: February 12, 1999  
Engineer: John Lynch  
Page: 1 of 1

**To: Distribution**

**Product: HK-322**

**Subject: IC type MN 6 0 6 0 replacement and Installation procedure**

In the HK-322 Base Station, IC – 33 “MN6060” in the SYNC module has been discontinued and is no longer available therefore it has been replaced by “60SUB BOARD” .

The 60sub board plugs into IC-33 socket with the cut corner of the sub board facing the front of the SYNC module, see drawing below.

At the diagonal corner from the pc cut are two capacitors with a +5V circle and feed through hole. Add an insulated jumper wire from this point to the main board at one side of R158 which has a feed through hole as shown below.

