

IKEGAMI TECHNICAL

# BULLETIN

37 Brook Avenue, Maywood, New Jersey 07607. (201) 368-9171, Fax (201) 368-2029

Ref No: 1088  
Date: 11-21-03  
Engineer: S. Miyatake/D. Disinger  
Page: 1 of 2

**To:** Distribution

**Product:** BS-366

**Subject:** G/Ret Video and R/B Video reliability

**It has been found that after a long period of time in service, dust accumulation on certain components can lead to a premature failure of those components. Therefore it is recommended to periodically clean the G/Ret Video and R/B Video boards of the BS -366 to remove accumulated dust. This cleaning can be performed with a dry low-pressure air source or a very soft brush. Care must be exercised not to inadvertently remove components. See the accompanying figures for the areas of concern.**



