

# HDK-725 Real Native 720P (1080i) Multi-Format HDTV Camera System



The HDK-725 camera system has been widely accepted by the broadcasters as it continues the change over to the HDTV formats. Ikegami offers the HDK-725 is now available for sports production and studio use. It is full compatibility with HDK-725P, and also colorimetry can be easily matched for the combination with portable camera.

Special Price:  
(with VF1767HD-R 7" CRT Viewfinder & CCU-790A)

**@\$35,000.-**

(FOB Maywood, NJ, with full warranty)  
(Quantities are limited, Pricing valid while supplies last)

Camera Head, Camera Control Unit and Viewfinder (Lens and Control Panel are not included)

- **Employs IT 2/3" native 720p CCDs**

- **Simulcast (HDTV and SDTV)**

Both HDTV video and SDTV (NTSC) are provided simultaneously from the CCU and in both digital and analog form. Monitoring video signals (WFM and PM) are likewise provided in both HDTV and SDTV to adapt to different system installations and to permit continued use of conventional monitoring.

- **Camera Control Unit, the CCU-790A**

The Ikegami HDK-series HDTV cameras are designed as a Multi-Use Camera to meet the format requirements of HDTV and SDTV have incorporated next-generation 0.18 micro m ASICs into new Camera Control Unit, the CCU-790A. Also includes the Ikegami ASICs, an Engine Board has been developed to achieve Frame and Multi-Format Conversion. (24p, 30p, 50p, 720p, 1080i, 480i, etc.)



- **High Performance Viewfinder**

VF1767HD-R 7-inch CRT B&W viewfinder.

- **Package include**

HDK-725 Camera Head  
VF1767HD-R 7" CRT B&W Viewfinder  
CCU-790A Camera Control Unit  
ENGINE1-1 Engine Board

**With Full Warranty** (1 year parts and labor, 2 years imaging sensors)

<http://www.ikegami.com>

**Ikegami Electronics (U.S.A.) Inc.**

Headquarters : 37 Brook Avenue, Maywood, New Jersey 07607 /

Phone 201-368-9171 Fax 201-569-1626

West Coast Office: Phone 310-297-1900

Southwest Office: Phone 972-869-2363

Midwest Office: Phone 614-834-1350

Southeast Office: Phone 954-571-7177