

Ikegami

TOSHIBA
Leading Innovation >>>

GFTM STATION PORTABLE

PORTABLE FLASH MEMORY RECORDER GFS-P10



The GFSTATIONTM PORTABLE is a compact and light weight recorder/player which uses GFAKTM as recording media. The GFSTATIONTM PORTABLE has many high performance features of the larger GFSTATIONTM including, clip by clip recording/playback, and PLAYLIST recording/playback.

Features

- JOG/SHUTTLE dial provides popular VTR-like operability. JOG playback(±1x speed), SHUTTLE playback(±60x speed) and Variable playback(±2x speed) are available.
- Thumbnail display enables to search and playback on the display.
- Both AC and DC Power operation is possible to meet outdoor shooting, OB-Van installation, and other requirements, for field operation.
- Built-in Up/Down converter.



JOG/SHUTTLE

- Supports popular machine control interface such as RS-422A and TBC Remote, enable to remote control from a variety of controller options.
- PLAYLIST editing and playback are possible.
- Front control panel tilt mechanism
- Employs 3.5-inch LCD monitor and loud speaker.



Tilt mechanism

Specifications

Rating

Power Requirement	100VAC ~ 240VAC, 50/60Hz +11VDC ~ +17VDC
Power Consumption	100W or less
Operating Temperature	0 ~ +40 °C (+32 ~ +104°F)
Storage Temperature	-20 ~ +60 °C (-4 ~ + 140°F)
Ambient Humidity	10% ~ 80% without condensation
Dimensions	W210 x H126 x D400 mm (W8.27 x H4.96 x D15.75 inch) excluding protrusion
Weight	9 kg (19.84 lbs) or less

Video Interface

HD/SD SDI Input(Selectable)	1x BNC Video: Conforms to SMPTE292M/259M Audio: Conforms to SMPTE299M/272M
HD/SD SDI Output(Selectable)	1x BNC, 1x BNC(Super-Impose ON/OFF) Video: Conforms to SMPTE292M/259M Audio: Conforms to SMPTE299M/272M
SD SDI Output(Selectable)	1x BNC(Super-Impose ON/OFF) Video: Conforms to SMPTE259M Audio: Conforms to SMPTE272M
Analog Composite Output	1x BNC(Super-Impose ON/OFF)

Audio Interface

Digital Input	2 x BNC, Conforms to AES3id-1995(48KHz)
Digital Output	2 x BNC, Conforms to AES3id-1995(48KHz)
Analog Input	2 x XLR
Analog Output	2 x XLR
Analog Monitor Output	2 x XLR
Headphone Output	1 x Stereo Mini Jack
Loud Speaker	1 x Monaural

System Interface

Time-code Input	1x BNC, SMPTE12M
Time-code Output	1x BNC, SMPTE12M
Reference Signal Input	1x BNC, Tri-Level Sync or Black Burst
Reference Signal Output	1x BNC, Loop-thru
RS-422A	1x D-SUB 9pin
TBC Remote	1x Amphenol, Half-pitch 20pin
GbitEthernet	1x RJ45, 1000Base-T (disabled)
External	1x eSATA
USB	1x USB2.0, A-Terminal



Rear Panel

Design and specifications are subject to change without notice.

● **GF**™ is trademarks of Ikegami and Toshiba.
● **GF SERIES** is co-developed product of Ikegami and Toshiba.

Ikegami **IKEGAMI ELECTRONICS (U.S.A.), INC.**

■ URL <http://www.ikegami.com>

H178A103-SELF

HEADQUARTERS 37 BROOK AVENUE, MAYWOOD, NJ 07607
Phone:(201) 368-9171 Fax:(201) 569-1626

WESTCOAST OFFICE Phone:(310) 297-1900
MIDWEST OFFICE Phone:(614) 834-1350

SOUTHWEST OFFICE Phone:(972) 869-2363
SOUTHEAST OFFICE Phone:(954) 735-2203