

# Ikegami

**TOSHIBA**  
Leading Innovation >>>

## GF<sup>TM</sup> PLAYER

PORTABLE FLASH MEMORY PLAYER GFS-V10PL



The GFPLAYER<sup>TM</sup> is compact, low profile player only, used to check clips on a GFPAK<sup>TM</sup> quickly and easily. PLAYLIST created on a GFSTATION<sup>TM</sup>, GFSTATION<sup>TM</sup> PORTABLE, or GFCAM<sup>TM</sup> Camera recorder can also be played back.



**Features**

- JOG playback and SHUTTLE playback(±30x speed)
- DC Power operation for outdoor shooting, OB-Van installation and other field applications.
- RS-422A(9pin) interface enables to remote control.
- 2 rows of 20 letters VFD display indicates menu or status information.
- Supports OSD function to display information on a video monitor.
- HD or SD SDI video outputs on BNC connectors
- DVI-D video output for monitoring video with a standard computer monitor.

**Specifications**

**Rating**

Power Requirement	100VAC ~ 240VAC, 50/60Hz +11VDC ~ +17VDC
Power Consumption	30W or less
Operating Temperature	-5 ~ +40 °C (+23 ~ +104 °F)
Storage Temperature	-20 ~ +60 °C (-4 ~ + 140 °F)
Ambient Humidity	10% ~ 80% without condensation
Dimensions	W210 x H88 x D350 mm (W8.27 x H3.47 x D13.78 inch) excluding protrusion
Weight	4 kg (8.82 lbs) or less

**Interface**

HD/SD SDI Output	1x BNC, 1x BNC(Super-Impose ON/OFF) Video: Conforms to SMPTE292M/259M Audio: Conforms to SMPTE299M/272M
Digital Audio Output	1x BNC, Conforms to AES3id-1995(48KHz)
Monitor Audio Output	2x XLR(3pin) 600ohm Balanced, 0dBm/4dBm, 2ch Menu Selectable
Headphone Output	1x Stereo Mini Jack
DVI-D Output	1x Characters overlaid
RS-422A	1x D-SUB 9pin
GbitEthernet	1x RJ45, 1000Base-T (disabled)
External	1x eSATA
USB	1x USB2.0, A-Terminal



Rear Panel

Design and specifications are subject to change without notice.

● GF™ is trademarks of Ikegami and Toshiba.  
● GF SERIES is co-developed product of Ikegami and Toshiba.

H179A103-SELF

**Ikegami** **IKEGAMI ELECTRONICS (U.S.A.), INC.** ■ URL <http://www.ikegami.com>

**HEADQUARTERS** 37 BROOK AVENUE, MAYWOOD, NJ 07607  
Phone:(201) 368-9171 Fax:(201) 569-1626

**WESTCOAST OFFICE** Phone:(310) 297-1900  
**MIDWEST OFFICE** Phone:(614) 834-1350

**SOUTHWEST OFFICE** Phone:(972) 869-2363  
**SOUTHEAST OFFICE** Phone:(954) 735-2203