

Ikegami®

7" Cable Ready NTSC TV/Monitor **V-ASL7000**



The V-ASL7000 is Low reflection high resolution TFT LCD/Monitor with Tuner. Features include Cable ready NTSC tuner with Booster interior Rod antenna or CATV feed, 2 channels of Video/Audio input plus switched output of on screen image and audio for routing to another display. Audio can be transmitted to a close proximity FM receiver. There are 5 screen format zoom settings and the image can be inverted for ceiling mount applications. The V-ASL7000 includes User manual, Full function Remote Control, 14 VDC power supply (requires 120 VAC), Mounting Bracket/Pedestal, Video Input cable and RF Cable TV adapter. PAL model also available.

■ SPECIFICATIONS:

Viewing Area:	6.125" (H) x 3.375" (V)	FM Transmitter:	87.5 to 89.5 MHz
Aspect Ratio:	4 : 3	Tuner:	NTSC/VHF/UHF/CATV
Pixels:	1440 (H) x 234 (V)		
Contrast Ratio:	100 : 1	Dimensions:	Width 7.375 Inch
Display:	7" High Resolution TFT		Height 4.625 Inch
Brightness:	200 cd		Depth 1.0 Inch
Power Requirement:	10-16 VDC, 1600 mA	Weight:	1.75 lbs (Approx.)

Design and specifications are subject to change without notice.

0604SKr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	773 Bearden Waxahachie, TX 75167 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227