

# Ikegami®

7.9" High-Resolution LCD Monitors

## V-LCD8-PRO



The V-LCD8-PRO is the latest low price stand alone monitor available from Ikegami. Its sleek design makes it ideal for any indoor or outdoor mobile monitoring application. The unit comes with a 1/4-20 mount located on the bottom of the unit for mounting purposes. Inputs include an NTSC/PAL auto recognition composite and a S-Video input, both with loop through capability. This unit is also equipped with our new bayonet locking 12 VDC power supply, ensuring that the power to the unit will not come undone while being handled. The unit is NTSC/PAL auto recognition and has an on-screen display to access color, tint, contrast and brightness controls.

### SPECIFICATIONS:

Viewing Area:	6.35" (H) x 4.65" (V)	Video Input:	1 X Composite NTSC
Aspect Ratio:	4 : 3		1 X S-Video
Pixels:	1440 (H) x 234 (V)	System:	NTSC/PAL Auto Detect
Dot Pitch:	0.112mm x 0.504mm	Dimensions:	Width 9.41 Inch
Display:	7.9" LCD		Height 6.25 Inch
Brightness:	350 cd		Depth 1.50 Inch
Power Requirement:	12 VDC, 3 Amp.		Weight 1.7 lbs.

Design and specifications are subject to change without notice.

**Ikegami** Ikegami Electronics ( U. S. A. ) Inc.

 URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C4, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227