

Ikegami®

15" LCD Monitor with Tuner, Quad Splitter,
Sterio Audio and Sequential Switcher / Router

V-R154P



This panel has 1024 × 768 pixels making it a true high resolution video LCD panel. The Quad Splitter allows all of the four channels to appear on the monitor simultaneous either using the full screen or picture-in-picture fashion. The unit fits into a EIA standard 19" rack, eight rack spaces high. The unit is controlled and calibrated using an on screen display while using the front mounted buttons to adjust. The built-in audio system has four balanced stereo inputs that are mono compatible which automatically default to the video source selected or can select any audio source to accompany any video source. For added flexibility, this unit can accomodate NTSC/PAL composite video, S-video or XGA for computer monitoring (TV, S-Video and XGA inputs are only available in full screen mode). Unit comes complete with power supply and owners manual.

■ SPECIFICATIONS:

Viewing Area:	11.69" (H) x 9.12" (V)	Video Input:	4 X Composite NTSC / PAL
Aspect Ratio:	4 : 3		S-video (Y + C)
Pixels:	1024 (H) x 768 (V)		TV tuner and XGA
Dot Pitch:	0.29mm x 0.3mm	Audio Input:	8 X XLR balanced
Display:	15.1" Active Matrix LCD	Dimensions:	Width 19.12 Inch
Brightness:	250 cd		Height 13.8 Inch
Power Requirement:	12 VDC, 5 Amp.		Depth 3.7 Inch

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227