

Ikegami®

17" High Resolution LCD Monitor
with Quad Splitter and Sequential Switcher

V-R171P-4



The V-R171P-4 is a 17" LCD rack mounted unit that features Quad Splitter and Sequential Switcher. This high resolution LCD panel has 1280 × 1024 pixels and fits in a standard 19" rack 8U high. The Quad Splitter allows all four channels to appear on the monitor simultaneously either using the full screen or picture-in-picture fashion. Other features include digital freeze and zoom functions as well as 16:9 aspect ratio via an on screen menu. For added flexibility, this unit can accommodate 4 NTSC/PAL composite video, 1 S-video or 1 SXGA for computer monitoring (S-video and SXGA inputs are only available in full screen mode). Unit comes complete with power supply and owners manual.

■ SPECIFICATIONS:

Viewing Area:	13.3" (H) x 10.64" (V)	Video Input:	4 X Composite NTSC / PAL
Aspect Ratio:	4 : 3		1 X S-video (Y + C)
Pixels:	1280 (H) x 1024 (V)		1 X SXGA
Dot Pitch:	0.26mm x 0.26mm	Dimensions:	Width 19.12 Inch
Display:	17" Active Matrix LCD		Height 13.8 Inch
Brightness:	250 cd		Depth 2.5 Inch
Power Requirement:	12 VDC, 3 Amp.		

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227