



The V-R171P-HDA is a rack-mounted monitor with a 17", 5:4 aspect ratio active matrix LCD/TFT module. Mounting can also be achieved via a VESA 75 reinforced mount point on the rear of the unit. The display will produce a high-resolution 1280H x 1024W SXGA image from a computer or display scaled video images. Component video, Composite video or Y/C (S-video) images are displayed via a scaling chip with a separate DVI-D input for video or computer. The unit fits into an EIA standard 19" rack and occupies 8RU of space. For ease of operation the V-R171P-HDA includes front mounted selector buttons for menu operations with On Screen Menu Display (OSD) and "ON AIR" tally. A U.L. Class 2 power supply is included and the unit is factory ready for rack mount installation. (Desk stand also available)

### **■** SPECIFICATIONS:

Viewing Area:	13.30" (H) x 10.64" (V)	Video Input:	1 S-Video (4 Pin Mini Din), 1 Composite (BNC), 1 SXGA (15P HD-15), Component Video (3 BNC), DVI-D (Digital only),
Aspect Ratio:	16 : 9 / 4 : 3	Dimensions:	Width 19.125 Inch Height 13.8 Inch Depth 3.0 Inch
Pixels:	1280 (H) x 1024 (V)	Weight:	12.5 lbs (Approx.)
Dot Pitch:	0.264mm square pixel		
Display:	17" Color TFT LCD		
Brightness:	300 cd		
Power Requirement:	12 VDC, 3.0 Amp.		

Design and specifications are subject to change without notice.

0605SKr1

**Ikegami** Ikegami Electronics ( U. S. A. ) Inc

**■** URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	773 Bearden Waxahachie, TX 75167 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227