

Ikegami®

Ten 2.5" LCD Monitor in 3U

V-R25P-SDI



The V-R25P-SDI is a rack mountable unit that has ten 2.5" active matrix LCD panels with SDI inputs and reclocked loop through feature. These 2.5" panels have 480 x 234 pixels producing a true high resolution image. This unit, as well as all Marshall rack mounted panels have a unique feature that allows the unit to tilt up or down for optimum viewing angle. The unit fits into an EIA standard 19" rack, 3U high. Each screen has NTSC/PAL auto-signal recognition. If there is no video signal present, a blue screen will appear. Unit is turned on and off by using the small toggle switch located on the side of the unit and is accessed by tilting the unit down. The unit includes power supply, instructions and dry erase marker for labeling screens.

■ SPECIFICATIONS:

Viewing Area:	1.97" (H) x 1.48" (V)	Video Input:	10 X SDI with reclocked loop through
Aspect Ratio:	4 : 3		
Pixels:	480 (H) x 234 (V)		
Dot Pitch:	0.105mm x 0.161mm	Dimensions:	Width 19.125 Inch
Display:	2.5" Active Matrix LCD		Height 5.14 Inch
Brightness:	250 cd		Depth 2.65 Inch
Power Requirement:	12 VDC, 5 Amp.	Weight:	5 lbs (Approx.)

Design and specifications are subject to change without notice.

0604SKr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227