

Ikegami®

Three 4" LCD Monitors in 2 RU

V-R43P



The V-R43P is a rack mountable unit that offers three 4" high-resolution active matrix LCD panels. Each of the three 480 x 234 pixel screens has its own set of controls for color, tint, contrast, and brightness. Each panel has also two composite video inputs with loophrough capability, a self-powered 3 color tally system, and auto-recognition of NTSC or PAL video formats. This unit is only 2 rack units high, and can be tilted up to 90 degrees while rack mounted, making it the smallest video monitoring system of it's kind. Like all of the V-R Series, this unit is constructed of steel and aluminum, and comes complete with power supply and owners manual.

■ SPECIFICATIONS:

Viewing Area:	3.23" (H) x 2.43" (V)	Video Input:	4 X Composite NTSC / PAL
Aspect Ratio:	4 : 3		
Pixels:	480 (H) x 234 (V)		
Dot Pitch:	0.17mm x 0.26mm		
Display:	4" Active Matrix LCD	Dimensions:	Width 19.125 Inch
Brightness:	300 cd		Height 3.43 Inch
Power Requirement:	12 VDC, 2 Amp.		Depth 2 Inch

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227