

Ikegami®

Four 4" LCD Monitors with SDI in 2 RU

V-R44P-SDI



Introducing the worlds smallest 4" quad rackmount with SDI inputs! The V-R44P-SDI is a rack mountable unit that offers four 4" high-resolution active matrix LCD panels. Each of the four 480 x 234 pixel screens has its own set of controls for color, tint, contrast, and brightness. Each panel also has a SDI input with active loop through feature, a D/A converter, a self-powered 3 color tally system and is switchable for NTSC or PAL formats. This unit is only 2U high, and can be tilted up to 90 degrees while rack mounted, making it the smallest video monitoring system of it's kind. All V-R Series models are constructed of steel and aluminum, and include power supply and operation manual.

- Ultra-compact design fits in EIA standard rack 2U high
- High Resolution, 480 x 234 pixels, 112,320 total
- Four SDI to composite video converters (one per channel) built-in
- SDI active loop through with active clock recovery and automatic 75W termination
- Ultra bright panels with 300 candle luminance each
- Switchable for NTSC/PAL formats
- Individual color, tint, brightness and contrast controls for each panel
- Three color, self-powered tally system provided for each panel
- Unique 100 degree tilt adjustment while mounted in rack
- Dry Erase Marker for EZ Identifying of screens is included

SPECIFICATIONS:

Viewing Area:	3.23" (H) x 2.43" (V)	Video Input:	4 X Serial Digital
Aspect Ratio:	4 : 3		Switchable for NTSC/PAL
Pixels:	480 (H) x 234 (V)		
Dot Pitch:	0.17mm x 0.26mm	Dimensions:	Width 19.125 Inch
Display:	4" Active Matrix LCD		Height 5.14 Inch
Brightness:	300 cd		Depth 2.5 Inch
Power Requirement:	12 VDC, 3.5 Amp.		Weight 5 lbs.

Design and specifications are subject to change without notice.

Ikegami Ikegami Electronics (U. S. A.) Inc.

 URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	773 Bearden Waxahachie, TX 75167 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227