



Three 5" LCD Monitors with SDI in 3 RU

V-R53P-SDI



The V-R53P-SDI is a rack mountable unit that has three independently controlled 5" active matrix LCD panels with loopthrough capability. These 5" panels have 960 x 234 pixels making them a true high resolution LCD panel. Each monitor has a composite video, SDI, and a VGA input. Each of the three screens also has a built-in color bar generator, individual front mounted selector buttons with LED's and color, tint, brightness and contrast controls. The unit fits into a EIA standard 19" rack, three rack spaces high. In addition to the digital and analog loopthroughs, this unit also has a 10-bit converted output from the digital input. Unit comes complete with power supply and dry erase marker and is available in either NTSC or PAL format.

■ SPECIFICATIONS:

Viewing Area:	4.75" (H) x 2.95" (V)	Video Input:	3 X Composite NTSC
Aspect Ratio:	4 : 3		3 X Serial Digital
Pixels:	960 (H) x 234 (V)		3 X VGA per panel
Dot Pitch:	0.11mm x 0.32mm	Dimensions:	Width 19.125 Inch
Display:	5" Active Matrix LCD		Height 5.14 Inch
Brightness:	350 cd		Depth 3.75 Inch
Power Requirement:	12 VDC, 2 Amp.		

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227