

Ikegami®

Three 5.8" LCD SDI Monitors with 16:9 aspect

V-R63P-SDI



The V-R63P-SDI is a rack mountable unit that has three independently controlled 5.8" active matrix LCD panels with loop through capability. These 16:9 high-resolution panels have a pixel count of 1200 x 234, and are rated at a very bright 350 candle luminance. Each panel has an SDI and a composite video input with a NTSC/PAL switch on the back. Each of the three screens has a built-in color bar generator, controls for color, tint, contrast, and brightness, and a selectable aspect ratio of 16:9 or 4:3. A built-in 3 color tally system is also provided for each screen. The unit comes complete with power supply, and fits into any standard EIA 19" rack, at only 3 RU high.

■ SPECIFICATIONS:

Viewing Area:	5.01" (H) x 2.83" (V)	Video Input:	3 X Composite NTSC
Aspect Ratio:	16 : 9		3 X Serial Digital Input
Pixels:	1200 (H) x 234 (V)		Built in bar generator
Dot Pitch:	0.11mm x 0.31mm	Dimensions:	Width 19.125 Inch
Display:	5.8" Active Matrix LCD		Height 5.14 Inch
Brightness:	350 cd		Depth 3.75 Inch
Power Requirement:	9 VDC, 3 Amp.		Weight 5 lbs.

Design and specifications are subject to change without notice.

0303JTLr2

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227