

Ikegami®

7" wide 16:9 aspect LCD Monitor

V-R70P



The V-R70P is the latest of the V-R Series from Ikegami Electronics. This unit is designed to work as a stand alone, camera or rack mounted monitor in a Leader or Tectronix Rackmount cradle. This unit can accommodate an NTSC composite video signal, or a S-Video signal. It has front mounted buttons with LED's and controls for brightness,color, tint, and contrast. A Ratio button allows the unit to switch between 16:9 and 4:3 ratios.Its 10VDC-17VDC power requirements make it ideal for field use and it can be powered from Anton Bauer or similar battery systems by using a special adaptor. Like all the V-R Series, this unit is built out of steel and aluminum for years of durability yet weighs only 1.8 lbs. making it ideal for use on top of a camera or camcorder (use optional hotshoe adapter V-LCD-MT).

■ SPECIFICATIONS:

Viewing Area:	6.07" (H) x 3.41" (V)	Video Input:	1 Composite NTSC
Aspect Ratio:	16 : 9		1 S-video (Y + C)
Pixels:	1440 (H) x 234 (V)		
Dot Pitch:	0.11mm x 0.38mm	Dimensions:	Width 8.25 Inch
Display:	7" wide LCD		Height 5 Inch
Brightness:	400 cd		Depth 1.4 Inch
Power Requirement:	10~17 VDC, 0.6 Amp.		

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227