

Ikegami®

7.9" LCD Monitor with Audio

V-R81PA



The V-R81PA is a rack mountable unit that has a 7.9" active matrix LCD panel with auto NTSC/PAL recognition and 4 separate channels of audio built-in. The video portion has 2 composite video inputs and an S-Video input, each with loop through capability. The four channels of audio are inputted via 4 balanced XLR inputs and have a passive loopthrough for each channel. Simultaneous visual monitoring of the 4 audio channels is obtained using the LED bar graphs on the face of the unit. Each speaker can have any of the 4 audio channels and are indicated by a highly visible LED number readout. Complete controls for color, tint, contrast, and brightness are provided via on-screen menu. The unit comes with power supply, and fits into any standard EIA 19" rack, at 4 rack units high.

■ SPECIFICATIONS:

Viewing Area:	6.35" (H) x 4.64" (V)	Video Input:	2 Composite NTSC / PAL
Aspect Ratio:	4 : 3		1 S-video (Y+C)
Pixels:	1440 (H) x 234 (V)	Audio Input	4 Analog with loopthrough
Dot Pitch:	0.11mm x 0.5mm	Dimensions:	Width 19,12 Inch
Display:	7.9" active matrix LCD		Height 6.85 Inch
Brightness:	350 cd		Depth 2.5 Inch
Power Requirement:	12 VDC, 3 Amp.		

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227