

# Ikegami®

## Dual 7.9" LCD Monitor with SDI **V-R82P-SDI**



The V-R82P-SDI is a rack mountable unit that has two 8.4" active matrix LCD panels. These panels have 800 × 600 pixels making them true high-resolution screens with a brightness of 350 candle luminance. Each panel has a composite video, SDI and VGA input with loop through capability, and auto recognition for NTSC or PAL. For added flexibility, an independent 3 color tally system is provided for each panel. Complete controls for color, tint, contrast, and brightness are provided via an on-screen menu. The unit comes complete with power supply, and fits into any standard EIA 19" rack, at 4 rack spaces high.

### **■** SPECIFICATIONS:

Viewing Area:	6.71" (H) x 5.03" (V)	Video Input:	2 Composite NTSC / PAL
Aspect Ratio:	4 : 3		2 Serial Digital Input
Pixels:	800 (H) x 600 (V)		2 VGA
Dot Pitch:	0.21mm x 0.21mm	Dimensions:	Width 19.125 Inch
Display:	8.4" active matrix LCD		Height 6.85 Inch
Brightness:	350 cd		Depth 2.5 Inch
Power Requirement:	12 VDC, 3 Amp.		

Design and specifications are subject to change without notice.

0502JTLr1

**Ikegami** Ikegami Electronics ( U. S. A. ) Inc.

**■** URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227