

TECHNICAL BULLETIN

Ikegami

37 Brook Avenue, Maywood, New Jersey 07607 • (201) 368-9171

Date: Sept. 21, 2009
Engineer: Alan Keil
Page: 1 of 1

To: Distribution
Product: MCP-200, OCP-200
Symptom: SD Memory Card compatibility

The maximum capacity SD memory card which can be used in the MCP-200 and OCP-200 is 512Mb. Typically over time larger capacity memory cards become available and at the same time it becomes increasingly difficult to source the original smaller capacity cards.

Ikegami has now updated software in the control panels to increase the maximum capacity SD memory card accepted by the MCP-200 and OCP-200 to 2Gb. If you require this change, please arrange this service update.

This service update requires changing the boot ROM data in one of the IC's. Since we do not recommend renewal of boot ROM data by customers, this service update should be performed at our New Jersey service center.

To arrange this service update, please contact customer service.